

IMPORTANT! KEEP FOR FUTURE REFERENCE

READ INSTRUCTIONS FULLY BEFORE USE

Runabout Toddler Daysacks: L10231/L10234/L10230/L10248
Animal Toddler Daysacks: L10247/L10239/L10241/L10255/L10256/L10242/L10238/L10246
Alpine 2 Toddler Daysacks: L10251/L10252

For children aged 6 months to 4 years old.

WARNINGS & SAFETY NOTICES

- **WARNING:** Be aware of the danger when using reins near automatic doors, escalators etc.
- **WARNING:** Remove any detachable reins when the harness is fitted into a child use and care article
- **WARNING:** Keep out of child's reach when not in use
- **WARNING:** Do not use this harness in motorised and power driven vehicles
- Do not leave the child unattended when harnessed into a child use and care article
- Check all straps and fastenings for signs of wear or damage before each use

FITTING AND USE

Place the child's arms through the shoulder straps and fasten chest strap. Tighten the shoulder straps until a secure fit is achieved, ensuring the pack remains central on the child's back. Do not overtighten and ensure the child is comfortable at all times.

Clip the rein-hook to the metal D-ring located at the top of the pack. Ensure that it is securely attached before use. Do not attach the rein to any other part of the pack. Always hold the rein with the hand loop and ensure a firm grip is maintained at all times.

CARE INSTRUCTIONS

To remove dirt, lightly brush with a soft brush or use a damp cloth and mild liquid soap.
Do not machine wash. Do not bleach. Do not store when damp.



IMPORTANT! À CONSERVER POUR CONSULTATION ULTÉRIEURE

LISEZ ATTENTIVEMENT LES INSTRUCTIONS AVANT TOUTE UTILISATION

'Runabout' Sacs à dos bambins: L10231/L10234/L10230/L10248

'Animal' Sacs à dos bambins: L10247/L10239/L10241/L10255/L10256/L10242/L10238/L10246

'Alpine 2' Sacs à dos bambins: L10251/L10252

Pour enfants de 6 mois à 4 ans.

AVERTISSEMENTS ET CONSIGNES DE SÉCURITÉ

- **ATTENTION:** Lorsque le sac est utilisé avec la bride de sécurité, faire extrêmement attention aux portes automatiques, escaliers roulants, etc.
- **ATTENTION:** Retirer toutes les brides détachables pour l'utilisation du harnais avec un article de puériculture
- **ATTENTION:** Ranger le produit hors de portée des enfants après utilisation
- **ATTENTION:** Ne pas utiliser ce harnais à l'intérieur d'un véhicule motorisé ou électrique
- Ne jamais laisser sans surveillance un enfant harnaché à tout autre article de puériculture.
- Avant utilisation, contrôler l'ensemble des sangles et attaches pour s'assurer qu'aucune partie n'est usée ou endommagée.

RÉGLAGE ET UTILISATION

Mettez le sac sur le dos de l'enfant en faisant glisser ses bras dans les bretelles, puis bouclez la sangle de poitrine. Resserrez les bretelles jusqu'à ce que le sac soit correctement positionné au milieu du dos de l'enfant. Attention à ne pas trop serrer, l'enfant doit être à l'aise dans ses mouvements.

Accrochez l'anneau de la bride de sécurité à l'anneau métallique en D situé sur le dessus du sac. Assurez-vous d'avoir bien attaché la bride avant toute utilisation. N'accrochez la bride à aucun autre endroit du sac. La poignée permet de maintenir fermement la bride et de ne pas la lâcher. Utilisez-la systématiquement.

CONSEILS D'ENTRETIEN

Brosser délicatement à l'aide d'une brosse souple, d'un chiffon humide et d'un savon liquide doux pour enlever les salissures. Ne pas laver en machine. Ne pas passer à l'eau de Javel. Ne jamais ranger un article humide. Attendre que l'article soit complètement sec avant de le ranger.

