


**ATTENTION! KEEP FOR FUTURE REFERENCE:
READ CAREFULLY!**

**INSTRUCTION MANUAL FOR USE OF PLAYPEN
AND CRIB WITH DROP SIDE „MERIDA”**

MERIDA



This playpen **chipolino** has been designed and manufactured in accordance with the Product Safety Directive 2001/95/EU of the European Parliament and the Council and to European standard EN 716 Children's cots and folding cots for domestic use, Safety requirements and testing methods as well as the regulations of national legislation including the consumer protection law.

**ATTENTION! YOUR CHILD WILL BE MOST SECURE IF YOU FOLLOW
THE INSTRUCTIONS AND RECOMMENDATIONS GIVEN IN
THIS USER'S MANUAL!**


ATTENTION!

1. **WARNING!** NEVER LEAVE THE CHILD UNATTENDED!
2. **WARNING!** MAKE SURE THIS PRODUCT IS NOT PLACED NEAR OPEN FIRE, OTHER SOURCE OF STRONG HEAT SUCH AS ELECTRIC BAR FIRES, GAS FIRES, ETC.!
3. **WARNING!** DISCONTINUE THE USAGE OF THIS PRODUCT, IF YOU FIND DAMAGED, TORN OR MISSING PARTS! USE ONLY SPARE PARTS OR OTHER COMPONENTS, WHICH ARE APPROVED BY THE PRODUCER! The producer does not take any responsibility for the safety of the child when you have not used the proper and original spare parts, approved and provided by him!
4. **WARNING!** DO NOT PLACE OBJECTS IN PLAYPEN OR NEAR IT WHICH CHILD CAN USE AS A SUPPORT OR ANY OTHER DANGEROUS OBJECTS CAUSING SUFFOCATION SUCH AS CORDS, STRINGS, ETC.!
5. **WARNING!** DO NOT USE MORE THAN ONE MATTRESS IN THE PLAYPEN!
6. **WARNING!** USE ONLY THE MATTRESS THAT IS INTEGRAL PART OF THIS PRODUCT AND DO NOT PUT ADDITIONAL MATTRESS IN PLAYPEN TO AVOID SUFFOCATION!
7. IF YOU LEAVE YOUR CHILD IN PLAYPEN WITHOUT ADULT SUPERVISION, MAKE SURE THAT DROP SIDE OF PLAYPEN IS LOCKED IN ITS HIGHEST POSITION!
8. ALWAYS before use the playpen make sure that locking mechanisms are fully engaged. Only then the playpen is safe for usage!
9. Bottom level of playpen is safest for your child. Use it for children who can sit unaided!
10. Use the second level of playpen only for children who **CANNOT** sit unaided and **CANNOT** roll or pushup with hands and knees!
11. All fasteners must be always well tightened. They must be regularly reviewed and tighten if needed.
12. The playpen must **NOT** be used for by a child who can climb and hand on it, because he/she can tip it over, fall down and get hurt!
13. The playpen must be used for one child at a time!
14. Playpen to be used for a child weighting not more than 15 kg.
15. Assembly, folding and unfolding of the playpen to be made only by adult!
16. Place the playpen only on horizontal and flat surface!
17. Always apply the parking device of playpen! USE THE WHEELS ONLY FOR MOVING THE PLAYPEN!
18. Do not allow children younger than 3 years near the stroller during the assembly or disassembly, in order to prevent the risk of injury or swallowing of small parts!
19. The packaging of the product must be kept out of the reach of children to avoid the risk of strangulation!

MAIN FEATURES

- Playpen is suitable for newborn babies and children aged less than 15 kg.
- Second level – suitable for younger babies
- Drop side
- Two wheels with parking devices
- Aside pockets for accessories
- Compact folding
- Carry bag

MAIN PARTS



Please, make sure all described parts below are available:

1. Playpen
2. Mattress
3. Tubes for the second level (4 pcs)
4. Carry bag
5. Second level

ASSEMBLY INSTRUCTION AND FUNCTIONS

This playpen is supplied partially assembled. In order to complete the assembly, you don't need any tools.

ATTENTION! Follow exactly the instructions given and check the pictures/figures.

ATTENTION! AFTER EACH OPERATION, MAKE SURE THAT YOU HAVE FOLLOWED THE INSTRUCTIONS CORRECTLY AND THE FIXING IS STABLE.

ATTENTION! Properly fixing is often accompanied with click sound.

ATTENTION! Be careful to avoid finger entrapment during each operation!

Assembly and functions are given in figures 1-6. Use all descriptions below together with figures with the same number.

1 – OPEN THE PLAYPEN

2 – FIRST LEVEL OF MATTRESS

3 – SECOND LEVEL OF MATTRESS






4 – DROP SIDE










5 – WHEELS AND PARKING DEVICES



6 – FOLDING AND PACKING

Note: Before folding the playpen you must remove the mattress, second level and all other additional accessories.



ATTENTION! Do not push stronger the rails if they don't fold from first time, because you may damage the mechanisms inside! Try again to follow all described actions.







Pull upwards the center of the playpen



Release the buttons of each rail (under the fabric). Fold the playpen



CARE AND MAINTENANCE

1. Do not push the rails mechanism strongly to avoid damages.
2. Clean the fabrics, plastic parts and metal parts with damp cotton cloth or sponge and mild soap.
3. Do not use abrasive, bleach or other aggressive detergents.
4. Always after cleaning leave the playpen and mattress fully dry and after that use them or store them. It may appear mold if you keep them moist.
5. Always store your product indoors. Do not expose to direct environment influence - sun, rain, moisture and high temperature intervals.
6. Please, contact your authorized dealer for problems connected with the use or repair of this product.

Fabric Composition:

Outer: 100% Polyester

Filling: 100% Polyester



Materials used: plastic, textile, metal.



1 Goliakonarsko shosse, Plovdiv, BULGARIA
www.chipolino.com