

Sennheiser SP 10 Speakerphone





Quick Guide
Kort vejledning
Kurzanleitung
Instrucciones resumidas
Guide rapide
Istruzioni brevi
Beknopte gebruiksaanwijzing
Krótka instrukcja obsługi



Package contents | Leveringsomfang | Lieferumfang | Volumen de suministro | Contenu | Dotazione | Omvang levering | Zakres dostawy



Connecting the speakerphone | Tilslutning af speakerphone | Speakerphone anschließen | Conexión del altavoz manos libres | Raccorder le speakerphone | Collegamento dello speakerphone | Speakerphone aansluiten | Podłączenie zestawu głośnomówiącego



For Instruction manual go to www.sennheiser.com/ccu/support

Adjusting the volume | Indstilling af lydstyrken | Lautstärke einstellen | Ajustar el volumen | Réglage du volume | Regolazione del volume | Het volume instellen | Regulacja głośności

Muting the microphone | Frakobling af lyd på mikrofon | Mikrofon stumm schalten | Silenciar el micrófono | Activation du mode silencieux du microphone | Silenziamento del microfono | Microfoon op mute schakelen | Wyciszenie mikrofonu





Sennheiser Communications A/S

Industriparken 27, DK-2750 Ballerup, Denmark
www.sennheiser.com

Printed in China, Publ. 05/15, A03

Using the speakerphone | Brug af speakerphone | Speakerphone verwenden | Uso del altavoz manos libres | Utiliser le speakerphone | Utilizzo dello speakerphone | Speakerphone gebruiken | Stosowanie zestawu głośnomówiącego

Call control features



Sennheiser SP 10 Speakerphone





Quick Guide
Instruções resumidas
Kısa Kılavuz
簡要説明
入門簡介
クイックガイド
Краткая инструкция
요약 설명서



Package contents | Material fornecido | Teslimat Kapsamı |
供货范围 | 包裝內容 | 同梱されているもの | Комплект
поставки | 구성품



Connecting the speakerphone | Ligar o telefone em alta voz | Speakerphone cihazını bağlayın | 连接扬声电话 |
免持聽筒連接 | 스피커폰을接続する | Подключение спикерфона | 스피커폰 연결



For Instruction manual go to www.sennheiser.com/cc/support

Adjusting the volume | Ajustar o volume | Ses seviyesini ayarlama | 調整音量 |
調節音量 | 音量を調節する | Регулировка громкости | 볼륨 조절하기

Muting the microphone | Activar o modo de silêncio no microfone |
Mikrofonu kapat | 麦克风静音 | 麥克風靜音 | マイクロホンをミュートする |
Отключение микрофона | 마이크 음소거



Sennheiser Communications A/S

Industriparken 27, DK-2750 Ballerup, Denmark
www.sennheiser.com

Printed in China, Publ. 05/15, A03

Using the speakerphone | Utilizar o telefone em alta voz | Speakerphone cihazını kullanın | 使用扬声电话 | 使用免持聽筒通話功能 | 스피커폰을 사용하는 | Использование спикерфона | 스피커폰 사용

Call control features

