










# 12 BIN TILTED STORAGE BINS FRAME



| NO. | DESCRIPTION              | QTY. | ITEM NO.      |
|-----|--------------------------|------|---------------|
| 1   | E-CORNER CONNECTOR       | 2    | 1060-W10-A1B2 |
| 2   | E-3-WAY CONNECTOR        | 4    | 1060-W10-B1G  |
| 3   | E-T SHAPE CONNECTOR      | 16   | 1060-W10-C1K  |
| 4   | E-4-WAY CONNECTOR        | 13   | 1060-W10-D1P  |
| 5   | E-5-WAY CONNECTOR        | 2    | 1060-W10-E1K  |
| 6   | E-TUBE END COVER         | 4    | 1060-W10-G1SR |
| 7   | E-105mm TUBE             | 16   | 1060-W17-C5SR |
| 8   | E-143mm TUBE             | 9    | 1060-W17-E8S  |
| 9   | E-216mm TUBE             | 36   | 1060-W17-F2S  |
| 10  | E-483mm TUBE             | 10   | 1060-W17-G1S  |
| 11  | E-RELEASE PLIERS         | 1    | 1060-W85-M1G  |
| 12  | E-105mm TUBE END SECTION | 4    | 1061-W17-C6S  |
| 13  | E-CROSS CONNECTOR        | 5    | 1136-W10-B1G  |
| 14  | E-U CLAPM & WASHER       | 2    | 1136-W90-E2S  |
|     |                          |      |               |

## **INSTRUCTION MANUAL**

### Assembled by an adult.

#### **IMPORTANT:**

This set is intended for adult assembly only. Please read all instructions carefully before beginning.

- 1. Keep unused parts in the marked bag(s) until required. Some parts appear similar and may be confused.
- 2. Assemble each section separately as shown in the exploded diagrams.
- 3. If parts need to be loosened, use the included "release pliers" to assist you.
- 4. After each section is complete, assemble the completed sections together into the final unit.

#### **ASSEMBLY & DISASSEMBLY**

· How to Assemble & Disassemble Tubes and Connectors

Note: Do not hold a tube or connector where the insertion takes place, fingers may be pinched.




Fig. 1

(2) Finish the assembly of both connectors with the tube in between. Then insert the connectors into two separate tubes to complete a panel. (Fig. 3-1)

Do not assemble the tubes and connectors one by one. (Fig. 3-2)




Fig. 3-1



Fig. 3-2

#### How to use U-Clamp Wall Attachment

If you want to fasten the storage frame to a wall, use the U-Clamp Wall Attachment and screws as shown in Figs. 5 & 6.".


• How to use Tube End Cover for Tube Insert Endcap into end of tube leg. (Fig. 7)

(1) Push the corner connector onto the tube and twist the tube until a "click" is heard.



Fig. 2

(3) Position the release plier nodes over the holes where the safety lock pins are visible. Squeeze gently to release the tube from the connector.






Fig


Fig. 5


Fig. 6


Fig. 7


## **12 BIN TILTED STORAGE BINS FRAME**














# GENIUS TOY TAIWAN CO., LTD. www.gigotoys.com