



soft developmental toys

INSTRUCTIONS FOR YOUR MUSICAL STACK & BALL GAME

Keep for future use



Teaches baby stacking, sorting and threading

Parts

Elephant Head
Electronic Stacking Cone
4 Balls
2 Rings
2 Links

Inserting the Batteries

1. Turn the toy over and loosen the battery compartment screw using a cross-headed (Phillips) screwdriver (Fig. 1).
2. Remove the cover and insert three new "AA" (1.5 v) batteries. (Fig. 2).
3. Replace the cover and tighten the screw firmly.



Fig. 1




Fig. 2

Playing with the Musical Stack & Ball game

1. Remove the links and rings from the toy.
2. Turn the toy over, and turn it on by moving the ON/OFF switch to the ON position (Fig. 3). You will hear a giggle sound to confirm that the toy has been turned on.
3. Now have your baby drop a ball into the top of the funnel-shaped elephant head – you will hear one of four sound effects and a musical tune. You will also see flashing lights. As your baby develops you may remove the head and have your baby drop the balls directly into the plastic cone, for a more challenging game. (Fig 4).



Fig. 3



Fig. 4

4. To retrieve the balls, open the small door at the bottom front of the toy, or turn the toy over and watch the balls spill out of the top. This is another important play feature for your baby.

5. At the end of play, turn the toy off by moving the ON/OFF switch to the OFF position.

6. Your baby can also play with the links and rings by stacking them on the cone, creating a chain or anything else that captures her imagination. (Fig 5).



Fig. 5

Cleaning and Storage

- ✿ Use a damp cloth to wipe clean.
- ✿ Do not immerse in water.
- ✿ Remove the batteries for long-term storage.

And Don't Forget These Safety Rules

- ✿ Batteries should be replaced by adults only.
- ✿ Do not mix old and new batteries.
- ✿ Non-rechargeable batteries are not to be recharged.
- ✿ Rechargeable batteries are to be removed from the toy before being charged.
- ✿ Rechargeable batteries are only to be charged under adult supervision.
- ✿ Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- ✿ Exhausted batteries are to be removed from the toy.
- ✿ Do not burn batteries. Dispose of batteries in a safe and appropriate manner.
- ✿ Use only batteries of the same or equivalent type as recommended.
- ✿ Batteries are to be inserted with the correct polarity.
- ✿ The supply terminals are not to be short-circuited.

For more developmental information and playing tips please visit:

© 2006 All rights reserved, Tiny Love Ltd.